

Features

- Station provides staff controls for room-level presence, request, code, staff emergency, staff rounding, and room reset functions
- Four configurable buttons
- Default button layout is L1, L2, Staff Emergency, and L3
- Button label insert options are provided for the 5 configurations available (see list below)
- Illuminated faceplate for low light visibility
- UL/cUL® 1069 and UL® 2560 Listed
- The Config Tool software has a built in label maker which allows customizing the button legend



SF124 Staff Peripheral Station

Description

The SF124 Staff Peripheral Station provides staff presence, staff request and staff rounding with programmable schedules, if so configured. Pressing a presence button activates an associated colored lamp on the associated corridor light. The connection to the IR42xP5-series station is supervised. Two-wire connections provide simple wiring.

Default button options (layouts included):

- L1, L2, Staff Emergency, L3 (Default)
- L1, L2, Staff Emergency, Reset
- L1, L2, L3, Reset
- L1, Code, Staff Emergency, Reset
- Round, Code, Staff Emergency, Reset

Listings



UL® 1069 Listed and cUL® Listed to CSA C22.2 No. 205; UL® File Number E71599.



RoHS Compliant

Specifications

Dimensions:	4.58"H × 3.25"W × 1.03"D (116 mm × 83 mm × 26 mm)
Environment:	0°C–60°C
Construction:	PC board with quality electronic components mounted to a membrane on a flame-retardant (UL® 94V-0) plastic faceplate
Mounting:	Attach the IH121K/IH122K back plate to a standard single-gang ring or single-gang ring and box
Housing:	Standard single-gang box
Connections:	2-wire flying lead

Required Components

NC455CE Central Equipment Module
IR42xP5-series Station
IH121K or IH122K Single and Dual Station Mounting Kits