



**For Details, Contact:**

**TekTone® Sales Dept.**  
Phone: 800-327-8466

TekTone® Sound & Signal  
277 Industrial Park Rd.  
Franklin, NC 28734

Fax: 828-524-9968  
E-mail: [tektone@tektone.net](mailto:tektone@tektone.net)

## TekTone® Sales Support Bulletin - No. 16

### **Wireless Pendant / Transmitter use with NC110N and NC150 Systems**

*Part Numbers involved: NC267 latching receiver and SF067 Pendant*

We can now use the SF067 and NC267 in the NC110/150N systems and allow for multiple priorities on the same lamp. Importantly, there are three scenarios.

1. The NC267 / SF067 can be used in conjunction with a patient station to place a routine call
2. The NC267 / SF067 can be used in conjunction with or instead of a smoke detector unit to place a 3rd priority call (using the PK153)
3. The NC267 / SF067 can be used as a stand alone unit to place one of the three available call priorities (using the PK153)

Please note, the one scenario that cannot be accomplished is using the pendant where a routine station and an emergency switch is present and the input of the pendant call is connected to the emergency switch.

The NC267 utilizes a latching relay and has a button for call reset. This must be considered when determining the location of the receiver. Access to the button must be allowed.

Important: 12 VDC power must be supplied from outside the TekTone system. An inexpensive plug-in transformer (especially for retrofitting) has been used in the past by some of our customers.

