

### Features

- Simple, push-button calling
- Call-placed indicator
- Cancel push button
- Call activates lamp on annunciator panel and corridor light
- Flame retardant (UL® 94V-0) plastic faceplate
- Corridor zone light capability

### Description

The SF101C Audible-Visual Room Station incorporates push-button operation of call and cancel functions. A call is registered at the annunciator panel and on a corridor light or corridor zone light (if installed) when the call switch with integral call-placed LED is pushed. The call-placed LED will also illuminate. Calls are canceled by simply depressing the cancel button. The call-placed LED will also be extinguished. All station components are mounted on a rugged UL® 94V-0 plastic faceplate.

### Listings



UL® 1069 Listed; UL® File Number E71599.

### Specifications

- Dimensions: 4.5"H × 2.75"W × 1.75"D  
(114 mm × 69 mm × 44 mm)
- Connections: Plug-in connectors
- Construction: Flame retardant (UL® 94V-0) plastic faceplate. Switches and electronic components are circuit board mounted
- Housing: Single-gang ring, or single-gang ring with dual-gang box



SF101C Audible-Visual Room Station

### Required Components

Tek-CARE® NC110 Nurse Call System