

### Features

- Automatic Tone Off reset
- Reliable and rugged design

### Description

The IR019B Remote Tone Speaker provides remote tone annunciation when connected directly to a PK2019A Power and Control Unit, and in parallel with a TekTone® CM800-series or DS100-series Annunciator Panel.

The tone speaker features a momentary contact Tone Off button for tone silencing. Depressing the Tone Off button silences the tone at all IR019B locations. The Tone Off light remains illuminated while tone-silencing is enabled. When the emergency initiating device has been reset, the Tone Off will automatically reset.

### Specifications

Dimensions:	4.5"H × 4.5"W (115 mm × 115 mm)
Finish:	Satin brushed stainless steel
Controls:	Individual replaceable push button with self-wiping contacts
Indicators:	28 volt red light
Speaker/Mic:	45-ohms, 2.5"
Connections:	Pigtails
Housing:	Standard dual-gang electrical box



IR019B Remote Tone Speaker

### Required Components

CM800 Emergency Call System  
or  
DS100 Door Sentry & Emergency Alarm System

PK2019A Power and Control Unit  
SS106 Transformer