

Features

- Easy Installation
- Mounted on a flame-retardant (UL® 94V-0) plastic panel
- Simple, reliable operation

Description

The JK300A Monitor Call Interface is for use in applications where a simple interface is needed to connect the monitor input of an IR300-series, IR400P5-series, or IR43xG3-series station to an external contact closure. The JK300A accepts a standard ¼" phono-type jacks and places a call if a plug is removed. A ¼" dummy plug is included for use when the monitor point is not connected to an external device. The JK300/2 Monitor Call Interface provides two ¼" jacks and two dummy plugs.

Applicable Systems

Tek-CARE®3000 Nurse Call System
IR33x-series Staff/Duty, Single/Dual Patient, or
Multipurpose Stations

Tek-CARE®570 Wireless Nurse Call System
SF571 Universal Transmitter

Tek-CARE®500 Wireless Emergency Caall System
SF525UL Universal Contact Transmitter

Tek-CARE®400 GEN3 Nurse Call System
IR43xG3-series Staff/Duty, Single/Dual Patient, or
Multipurpose Stations

Tek-CARE®400 P5/P5+ Nurse Call System
IR400P5/P5+-series Multipurpose, Patient, Resident,
Check-In, Staff, or Duty Stations

Tek-CARE®400 Nurse Call System
PM123 Auxiliary Input Module
IR400-series Multipurpose, Patient, Resident, Check-In,
Staff or Duty Stations

Tek-CARE®300III Nurse Call System
IR300-series Multipurpose, Patient, Staff or Duty
Stations

Tek-CARE®120 Nurse Call System
PM123 Auxiliary Input Module



JK300A, JK300/2 Monitor Call Interface

Specifications

Dimensions:	4.5"H × 2.75"W × 1.5"D × 0.25" (114 mm × 70 mm × 38 mm × 6.5 mm)
Construction:	Reliable components mounted on a flame-retardant (UL® 94V-0) plastic panel
Connections:	Wire lead pigtails
Housing:	Single-gang electrical box or ring