



PK800A Auxiliary Power Supply

IL664 Specification Sheet

Tek-CARE® NC110, NC150, NC200 Nurse Call Systems • Rev. 10 - 11/2016

Features

- UL® 1069 Listed
- Compact design
- Protected from shorts at the outputs

Description

TekTone®'s PK800A Auxiliary Power Supply provides additional DC power for the Tek-CARE® NC110, NC150 and NC200 Nurse Call Systems, allowing for extended light capacity. Both of the outputs, +24VDC and +5VDC, are protected from shorts that might occur at the output. When the shorts are removed, the power supply recovers and operates normally. A 4 amp fuse protects the input of the power supply.

The PK800A Auxiliary Power Supply maintains its output for approximately 2 seconds after removal of its input power. This feature prevents the loss of system functionality during periods of brief power interruptions.



PK800A Auxiliary Power Supply

Listings



UL® 1069 listed; UL® File Number E71599.

Specifications

Dimensions:	Height:	10.625"	(270 mm)
	Width:	3.5"	(88.9 mm)
	Depth:	2.5"	(64 mm)
Construction:	Extruded Aluminum case. Internal circuit board.		
Connections:	Screw Terminals		
Fuse:	4 amp		
Power:	24VAC / 100VA / 60Hz		

Required Components

Tek-CARE® NC110, NC150 or NC200 Nurse Call System
 IH151NK Power and Control Kit
 24VAC, 100VA transformer supplied by others

www.tektone.com

324 Industrial Park Road • Franklin, NC 28734 • tektone@tektone.net

Phone: (828) 524-9967 • Fax: (828) 524-9968 • Sales: Choose option 2 • Tech Support: Choose option 3
 TekTone®'s quality system is registered by DQS to the ISO 9001 standard. (Reference #10001510.)