



IR087A Apartment Intercom Station

IL723 Specification Sheet

Tek-ENTRY® Apartment Entry Systems • Rev. 5 - 12/2013

Features

- Simple push button operation
- Automatic privacy
- Easy installation
- Large panel covers most openings

Description

The IR087A Apartment Intercom Station is designed specifically for renovation use and is large enough to cover the area occupied by most existing intercom units, making repainting unnecessary. The reduced wiring requirement permits using the existing wiring (if in good condition), while the advanced electronic design permits use in large or small buildings. A wide variety of optional accessories is available to provide additional functions, such as dual entrance operation, post office door release and silent door operation.

Specifications

Dimensions:	Height:	8.75"	(222 mm)
	Width:	6.5"	(165 mm)
Construction:	Steel faceplate with white vinyl coat.		
Controls:	Individually replaceable type push buttons with self-wiping plated contacts. Identified for talk, listen, and door functions.		
Speaker/Mic:	3.5" (89 mm) with voice response. Also used for electronic tone signal.		
Mounting:	Mounting holes may be positioned to accommodate an existing back box. Supplied without holes or mounting screws.		

Required Components

PK543A Apartment Intercom Amplifier
PO001 Door Release
SS102A Transformer
AM192-, CM192- or AM600-series Entrance Panel



IR087A Apartment Intercom Station

www.tektone.com

277 Industrial Park Road • Franklin, NC 28734 • tektone@tektone.net

Phone: (828) 524-9967 • Fax: (828) 524-9968 • Sales: Choose option 2 • Tech Support: Choose option 3

TekTone®'s quality system is registered by UL® to the ISO 9001 standard. (Reference #10001510.)