



IR150B Staff Station Specification Sheet

IL726
Section E
Rev. 4 - 8/2010



IR150B

ARCHITECTS' AND ENGINEERS' SPECIFICATION

The staff station shall be TekTone®'s IR150B or approved equal. The staff station shall provide a call-placement indicator, call push button, combination reset button and in-use indicator, and a 2.5" × 2.5" speaker/microphone with voice response. The staff station electronics shall be mounted on a durable flame-retardant (UL® 94V-0) plastic panel. Connections shall be plug-in connectors.

The IR150B shall be UL® 1069 Listed.

FEATURES

The IR150B Staff Station provides for efficient use of the nursing staff by permitting fast reliable communication.

Used with TekTone®'s Tek-CARE® NC200 and NC150 nurse call systems, the IR150B provides reliable two-way, hands-free communication between the nurse master station and utility room, examination rooms, kitchen, or any other location where staff members may need to originate calls. Calls are placed by use of a momentary push button. Solid-state indicators on the panel indicate that a call has been placed and that the intercom is in use.

- UL® 1069 Listed
- May be used as a retrofit for the IR150N station with IH106N backbox; requires two CL207 mounting adapters.
- Push button calling
- Call-placed indicator
- In-use indicator when intercom audio path is active
- Reset button
- Sensitive speaker/microphone
- Attractive and durable flame-retardant (UL® 94V-0) plastic panel

SPECIFICATIONS

Dimensions:	Height:	4.5"	(119 mm)
	Width:	6.375"	(162 mm)
	Depth:	1.875"	(48 mm)
	Projects:	0.5"	(12.7 mm)
			above mounting surface
Construction:	Flame-retardant (UL® 94V-0) plastic		
Speaker:	2.5" × 2.5"		
Connections:	Plug-in type		
Housing:	Steel City #H3BD with Steel City #3GC plaster ring, or TekTone® #IH353 box with IH352 ring, or equal, or if a smaller box is needed, use ARC-CO #2GB with ARC-CO #3GC ring. Horizontal mount.		

REQUIRED COMPONENTS

Tek-CARE® NC200 or NC150 Nurse Call System

www.tektone.com

277 Industrial Park Road • Franklin, NC 28734 • tektone@tektone.net
Phone: (828) 524-9967 • Fax: (828) 524-9968 • Tech Support: Choose option 2 • Sales: Choose option 3
TekTone®'s quality system is registered by UL® to the ISO 9001 standard. (Reference #10001510.)