



IR150SS, IR150SS/S Remote Call Stations Specification Sheet

IL765
Section D
Rev. 5 - 02/2010



IR150SS flush mount
(IR150SS/S surface mount also available)

ARCHITECTS' AND ENGINEERS' SPECIFICATION

The remote call station shall be TekTone®'s IR150SS, IR150SS/S, or approved equal. The remote call station shall provide a call-placement indicator, a 2.36" (60 mm) mushroom-style call push button, a cancel button and an audio-on indicator. The station shall also include a 3.5" Mylar® speaker/microphone with voice response. The remote call station electronics shall be mounted on a durable brushed stainless steel panel. Connections shall be made via screw terminals. The station shall be weather resistant.

FEATURES

Used with TekTone®'s Tek-SAFE™ NC150R Area of Rescue Assistance System, IR150SS and IR150SS/S Remote Call Stations provide efficient communication between areas of rescue assistance (in protected stairwells) and the building lobby.

IR150SS and IR150SS/S Remote Call Stations are located in areas of rescue assistance to provide two-way hands-free communication to a central location from which help may be summoned. Calls are placed by pressing a large, 2.36" (60 mm) mushroom-style momentary push button. Solid state indicators on the panel indicate when a call has been placed and when the intercom is in use.

- Push button calling via large mushroom-style button
- Call-placed indicator
- Audio-on indicator
- Cancel button
- Sensitive speaker/microphone
- Attractive and durable stainless steel panel
- Weather resistant when properly installed

SPECIFICATIONS

Dimensions:	Height:	5" (127 mm)
	Width:	11.1" (282 mm)
	Depth:	1.75" (45 mm)
Projects:	1.5" (38 mm) above mounting surface (IR150SS)	
	3.5" (89 mm) above mounting surface (IR150SS/S)	
Construction:	Durable stainless steel panel	
Finish:	Brushed stainless	
Speaker:	3.5" Mylar®	
Button:	2.36" (60 mm) diameter	
Connections:	6-screw terminal block	
Housing:	TekTone® OH600 or equal for IR150SS; none required for IR150SS/S	

REQUIRED COMPONENTS

Tek-SAFE™ Area of Rescue Assistance System

www.tektone.com

277 Industrial Park Road • Franklin, NC 28734 • tektone@tektone.net
Phone: (828) 524-9967 • Fax: (828) 524-9968 • Tech Support: Choose option 2 • Sales: Choose option 3
TekTone®'s quality system is registered by UL® to the ISO 9001 standard. (Reference #10001510.)