

Description

The IH527 Surface-Mount Single-Gang Plastic Back Box is for use with the Tek-CARE®500 Wireless Emergency Call System. The back box is used to surface mount the SF527UL/SF337C Waterproof Emergency Switch assembly and the SF530UL Room Station.

The IH527 is constructed of durable ABS plastic to coordinate with the emergency switches, and does not interfere with wireless transmission signals. The back box includes mounting holes on the back for attachment to the wall. The SF527UL Wireless Check-In Emergency Station is placed inside the IH527, and then the SF337C Emergency Switch or the SF530UL Room Station is attached to the mounting holes on the front of the IH527.

Specifications

Material:	ABS Plastic		
Dimensions:	Height:	4.5"	(115 mm)
	Width:	2.85"	(72 mm)
	Depth:	2.56"	(65 mm)
	Plastic:	3 mm thick	

Required Components

Tek-CARE500 Wireless Emergency Call System

—plus one of these—

SF527UL Check-In/Emergency Station
SF337C Emergency Switch

SF530UL Wireless Room Station
SF301A-series Pushbutton Call Cord



IH527 Surface-Mount Single-Gang Plastic Back Box

TekTone® has designed Tek-CARE500 to work as a system. Its Tek-CARE® Server has been carefully designed and matched to work with Tek-CARE500 wireless and wired peripherals. TekTone will not warrant or support components of Tek-CARE500 that are purchased separately unless the components are add-ons to previously sold systems. TekTone will also not warrant or support a system that is a mix of TekTone and non-TekTone parts, unless prior permission has been obtained. A site survey must be performed and submitted before ordering a Tek-CARE500 system. In order to track our systems and to inform facilities of software upgrades, full site information (site name, address and phone number) will be required when ordering. Site information and Tek-CARE Server warranty numbers will also be required when requesting technical support.