

Features

- Attractive sconce fits over any TekTone® LED dome light.
- Eliminates the institutional feel in senior living facilities.
- Dome lights are clearly visible at least 15' away.
- Sconce mounts securely to the wall over the dome light.

Description

LI600 Sconces cover TekTone LED dome lights so that they blend in with the homey atmosphere desired in today's senior living facilities. Since the sconce attaches directly to the wall, it can be used in both new and pre-existing installations. With the decorative sconce in place, all color LEDs are equally visible from at least 15' away.

The LI600 Sconce is made of frosted glass with a base of iron with a painted coffee finish.

Specifications

Dimensions:	9.84"W × 9.45"H × 5.12"D (250 mm × 240 mm × 130 mm)
Weight:	1.75 lbs.
Mounting:	Mounts directly to the wall using two screws; use drywall anchors where needed. When using supplied drilling template, top of sconce is approximately 1.5" above top screw holes of dome light back box, and bottom of sconce is approximately 8" below top back box's top screw holes.
Construction:	Frosted glass, and iron with painted coffee finish.



LI600 Sconce for LED Dome Lights
(Shown over LI484P5 Dome Light with multicolor LEDs)

Applicable Components

For Tek-CARE®400 P5/P5+ Nurse Call Systems:
LI484P5 Dome Light – 4 multicolor LEDs

For Tek-CARE®400 Nurse Call Systems:
LI482LED Dome Light – 2 red, 2 white LEDs
LI484LED-1 Dome Light – amber, green, red, white LEDs
LI484ZLED Zone Light – amber, green, red, white LEDs

For Tek-CARE®NC300III Nurse Call Systems:
LI380LED Dome Light – amber, green, red, white LEDs
LI382LED Dome Light – 2 red, 2 white LEDs
LI386LED Addressable Dome/Zone Light – amber, green, red, white LEDs

For Tek-CARE®120 or 160 Nurse Call Systems:
LI122 Room Controller with Dome Light
LI484P5 Dome Light – 4 multicolor LEDs

For Tek-CARE®NC110, NC150, NC200 Nurse Call Systems:
LI382LED Dome/Zone Light – 2 red, 2 white LEDs