

NC403TS Tek-CARE Monitor IL1029 Specification Sheet

Tek-CARE Nurse Call Systems • Rev. 4 - 3/2024

Features

- Can be placed anywhere in the facility with LAN connectivity
- Touchscreen monitor for easy interaction
- Displays calls, icons, maps, station information, resident information, and much more
- Calls can be filtered and zoned
- Can operate as a non-interactive display if only a call display is desired
- Optional supervision

Description

The touchscreen NC403TS Tek-CARE Monitor is a purpose-built monitor for the Tek-CARE nurse call system. It is designed to be a cost-effective and attractive option for displaying calls throughout the facility where the full functionality of a master station is not required.

The NC403TS Tek-CARE Monitor is supplied as a complete unit which includes all the necessary hardware for connection to the nurse call system. The NC403TS Tek-CARE Monitor is connected to the Tek-CARE system via the facility's local area network (LAN). A CL234 wall-mount bracket may be purchased separately and used in conjunction with a VESA designed TV/Monitor wall- mount bracket.

The NC403TS Tek-CARE Monitor offers many functions used by facility staff on a daily basis, such as call display and the ability to view details about a call, resident information, status display, and more. In addition to a call list view, a map view and icon view are also available if desired. The NC403TS Tek-CARE Monitor can also modify its own annunciation settings and display system faults if desired. Password protection of advanced features is also available.

The NC403TS Tek-CARE Monitor can be zoned to display calls from desired zones to improve staff awareness and efficiency. Up to 254 NC403TS Tek-CARE Monitors can be installed on a single Tek-CARE system.



NC403TS Tek-CARE Monitor

Specifications

Demensions:	14"H × 21.3"W × 1.9"D (356 mm × 541 mm × 48 mm)
Connection:	Ethernet connectivity to facility LAN
Display:	24" touchscreen display

Required Components

NC475 Tek-CARE Appliance Server

Optional Components

CL234 Wall-Mount Bracket

www.tektone.com

324 Industrial Park Road • Franklin, NC 28734 • tektone@tektone.com Phone: 828.524.9967 • Fax: 828.524.9968 • Sales: Choose option 2 • Tech Support: Choose option 3 TekTone's quality system is registered by DQS to the ISO 9001:2015 standard.