



AM192 Series Entrance Panel Specification Sheet

IL318
Section A
Rev. 10-08/2010



AM192
with OF191 Frame

FEATURES

The AM192 Series Entrance Panel is a modular series for use with TekTone® apartment intercom stations.

Panels are equipped with a voice-frequency response speaker and can accommodate up to 18 push buttons per panel. For more than 18 apartments, the AM192 is used in conjunction with the AM190 series push button panels.

Pressing the button corresponding to the desired name and apartment number causes a buzzing at the apartment station. The resident may then converse with the caller. Controlled entry is permitted by push button operation of the electric door release, if desired. AM192 Panels with 4 to 10 buttons are available with postal option.

- Mounts on fully-enclosed back box with knockouts
- Modular design
- Hands-free loud-speaking
- Weather-resistant speaker
- Individually replaceable name holders (black flame retardant polycarbonate plastic)
- Self-wiping push button switches
- Slim-line surface-mount option
- Simple installation

ARCHITECTS' AND ENGINEERS' SPECIFICATION

The entrance panel shall be TekTone® AM192 Series, or approved equal, and shall provide up to 18 push buttons per panel.

Push button switches shall be individually replaceable with self-wiping contacts. In addition, the panel shall contain up to 18 individual name holders. The name holders shall be made of black flame retardant polycarbonate plastic with clear flame retardant polycarbonate plastic strips to protect card inserts. Each name holder shall snap into two small slots on the panel itself and shall be individually replaceable.

Each AM192 Panel, or approved equal, shall be supplied with name card sheets that may be easily separated into individual name strips. Name strips shall be inserted into name holders without the use of tools.

The panel shall be flush or surface mounted and shall be finished in brushed aluminum.

SPECIFICATIONS

Dimensions:	Height:	16.5"	(413mm)
	Width:	4" each panel	(100mm)
Push buttons:	Individually replaceable type with self-wiping contacts.		
Speaker:	2.5" (64 mm) voice frequency response.		
Construction:	Modular extruded, anodized aluminum panel with high-impact grill.		
Mounting:	OF/OH190 Series for flush mounting. For surface mounting, use OF190S Series Frame.		

REQUIRED COMPONENTS

IR Series	Apartment Intercom Stations
OF Series	Frame
OH Series	Housing
PK543A	Amplifier
SS Series	Transformer

www.tektone.com

277 Industrial Park Road • Franklin, NC 28734 • tektone@tektone.net
Phone: (828) 524-9967 • Fax: (828) 524-9968 • Tech Support: Choose option 2 • Sales: Choose option 3
TekTone®'s quality system is registered by UL® to the ISO 9001 standard. (Reference #10001510.)