

Features

- UL® 1069 Listed
- Easy bulb replacement
- Snap-in colored lens sections
- Excellent visibility
- Interchangeable lenses

Description

TekTone's LI380 Corridor Dome Light provides visual indication of calls originating from patient, staff, duty, bath, emergency, presence and code call stations. Patient priority and staff presence are indicated by amber, green, red and white colored lenses. When used with any room station or IR310E Staff Station, the LI380 indicates all calls originated from that room. When used with the IR300E Multipurpose Station or the IR315F Duty Station, the LI380 may be used as a zone light to indicate all calls from the zones to which those stations are assigned.

Listings



UL® 1069 listed; UL® File Number E71599.

Specifications

Dimensions:	Height:	4.5625"	(115 mm)
	Width:	4.5625"	(115 mm)
	Depth:	3.3"	(84 mm)
Bulbs:	#1829 28v. 70mA		
Power:	24 VDC, 205 mA		
Finish:	Base is flame-retardant (UL® 94V-0) plastic. Amber, green and red lenses are flame-retardant translucent polycarbonate plastic. White lens is flame-retardant translucent polystyrene plastic.		
Housing:	Fits standard dual gang box with either single gang ring or dual gang ring.		



LI380 Corridor Dome Light

Required Components

Tek-CARE®300II Nurse Call System