

Features

- Vandal-resistant panel and push-button actuators
- Hands-free loud-speaking
- Weather-resistant Mylar speaker
- Self-wiping push-button switches
- Decorative end caps
- Individually replaceable name holders
- Slim-line surface-mount option
- Simple installation

Description

The AM642-series Vandal-Resistant Entrance Panel is for use with TekTone® loud-speaker suite stations.

The anodized aluminum panel is available in two sizes. The 4.75" × 11.25" panel accommodates 2 to 8 push-buttons, and the 4.75" × 17.25" panel is used for applications requiring 10 to 16 push-buttons or a postal release option.

Panels are equipped with a weather-resistant Mylar speaker protected by a louvered panel and perforated aluminum material. The speaker panel can accommodate up to 16 push-button actuators. In addition, the panel also contains up to 16 name holders with plastic lenses that snap easily into the panel and are individually replaceable.

Specifications

- Dimensions: 11.25"H or 17.25"H × 4.75"W
(285 mm or 438 mm × 120 mm)
- Push-button: Individually replaceable type with self-wiping contacts
- Speaker: 2.5" (64 mm) voice frequency response
- Construction: Anodized extruded aluminum panel
- Housing, flush: OH600 Back Box for 2-8 buttons
OH601 Back Box for 10-16 buttons
- Surface mount: Add "S" to panel part number (example: AM642/10S)
- Name holders: 2.125" × 1.0625"



AM642-series Vandal Resistant Entrance Panel

Required Components

- IR100-series or IR200-series Apartment Stations
PK543A Apartment Intercom Amplifier
SS102A Transformer
OH600 or OH601 Back Box (for flush mounted models)