

Features

- Flame retardant ABS plastic end caps
- Provides postal lock installation of door release devices

Description

The PO101S Postal Door Release provides for postal lock installation and microswitch control of door release devices. It is constructed of a rugged aluminum panel with durable, flame retardant ABS plastic endcaps. The extrusion design provides sufficient depth to make the panel surface mountable with no additional housing required. A gasket is also attached to the rear surface to increase the station's resistance to weather exposure.

Specifications

Dimensions:	7.25"H × 4.9"W × 1.5"D (184 mm × 125 mm × 38 mm)
Construction:	Rugged extruded aluminum panel with durable, flame retardant ABS plastic endcaps
Finish:	Brushed aluminum



PO101S Postal Door Release

Required Components

Tek-ENTRY® Apartment Entry System
or
Tek-ENTRY® Vandal-Resistant Entry System