



NC399P Alphanumeric Pager CommtechWireless 7900 Specification Sheet

IL734
Section E
Rev. 6 - 08/2010



NC399P

FEATURES

The NC399P alphanumeric pager is a radio pager receiver with a large 2-line display, and is designed for use with TekTone's Tek-CARE®500 Wireless Emergency Call System, and TekTone's Tek-CARE®400, NC300II, NC200, NC150 and NC110 Nurse Call Systems. The pager stores up to 60 messages. Messages may be selectively deleted or locked into memory. Messages not locked into memory are automatically deleted as new messages arrive (beyond the 60 message limit), with the oldest messages being deleted first. The NC399P may be configured for annunciation via vibration or audible tones, and has one alarm for daily annunciation. It can be programmed to turn on and off at preset times each day.

The NC399P has been pre-programmed to receive call information from TekTone® systems. Its CAP code may be reprogrammed in the field.

- Alphanumeric
- 2-line backlit display
- Easy to use large 4-button design
- Configurable for audible or vibration alerts
- Field programmable
- Includes holster belt clip and safety cord

ARCHITECTS' AND ENGINEERS' SPECIFICATION

The alphanumeric pager shall be a TekTone® NC399P, or approved equal. It shall have a large two-line display and shall be capable of storing up to 60 messages. The unit shall have a four-button design for ease of operation and shall provide a choice of tone and vibrate modes for page annunciation. A holster belt clip shall be provided with each unit.

The pager shall be pre-programmed to receive patient call information from TekTone's Tek-CARE®500 Wireless Emergency Call System or TekTone's Tek-CARE®400, NC300II, NC200, NC150 or NC110 Nurse Call System, via TekTone's NC365/A/AT or NC366A/AT Transmitter/Control Units. The pager's CAP code shall be reprogrammable in the field. Alphanumeric patient call information shall be displayed as generated by the emergency or nurse call system and the pager shall generate annunciation by sound or vibration.

SPECIFICATIONS

Dimensions:	Height:	1.9" (49 mm)
		without holster belt clip
	Width:	2.7" (70 mm)
	Depth:	0.7" (19 mm)
Construction:	Electronic components surface mounted to PCB enclosed in ABS plastic housing	
Operating Freq.:	457.550 Mhz	
Power supply:	1.5 vDC (1 AA cell)	

APPLICABLE SYSTEMS

Tek-CARE®500	Wireless Emergency Call System
Tek-CARE®400, NC300II, NC200, NC150, NC110	Nurse call systems
NC365/A/AT	Transmitter/Control Unit
NC366A/AT	Transmitter/Control Unit
NC375	Transmitter Interface

Paging is an ancillary method of call annunciation, and is not intended to replace the primary annunciation provided by the nurse call system.

www.tektone.com

277 Industrial Park Road • Franklin, NC 28734 • tektone@tektone.net
Phone: (828) 524-9967 • Fax: (828) 524-9968 • Tech Support: Choose option 2 • Sales: Choose option 3
TekTone's quality system is registered by UL® to the ISO 9001 standard. (Reference #10001510.)