



SI005 LED Messaging Sign Specification Sheet

IL890
Section E
Rev. 2 - 08/2010



SI005

ARCHITECTS' AND ENGINEERS' SPECIFICATION

The alphanumeric LED message sign shall be TekTone® SI005. It shall have a large single-line display and shall be capable of storing up to 24 messages. The unit shall provide a choice of tone modes for page annunciation. The LED message sign shall be pre-programmed to receive patient call information from TekTone®'s Tek-CARE®500 Wireless Emergency Call System and Tek-CARE®400 Nurse Call System via TekTone®'s NC369 Paging Transmitter. The LED message sign shall be programmable for up to six CAP codes. The sign shall annunciate and display alphanumeric patient call information as generated by the emergency or nurse call system.

The LED message sign is an ancillary method of call annunciation, and is not intended to replace the primary annunciation provided by the nurse call system.

FEATURES

The SI005 LED Message Sign is a radio paging receiver with a large one-line alphanumeric display. It is designed for use with TekTone®'s Tek-CARE®500 Wireless Emergency Call and Tek-CARE®400 Nurse Call Systems. The SI005 stores up to 24 messages. The messages are deleted after a predetermined length of time. Messages are automatically deleted as new messages arrive (beyond the 24 message limit), with the oldest messages being deleted first. The SI005 may be configured for annunciation via audible tones. The SI005 has been pre-programmed to receive call information from TekTone® systems, and it can be programmed for up to six CAP codes.

- One-line backlit LED display
- Displays 10 to 40 alphanumeric characters per line
- Configurable for audible alerts
- Programmable for up to 6 CAP codes
- Wireless data input
- Receives text messages from either TekTone® system

SPECIFICATIONS

Dimensions: 28" L × 6.75" H (711 mm × 171 mm)
Weight: 8.4 lbs.
Construction: LED display board with RF paging circuitry enclosed in a plastic housing.
Operating Freq.: 457.550 Mhz
Power supply: Input 115 VAC

APPLICABLE SYSTEMS

Tek-CARE®400 Nurse Call System
Tek-CARE®500 Wireless Emergency Call System

REQUIRED COMPONENT

NC369 Paging Transmitter

www.tektone.com

277 Industrial Park Road • Franklin, NC 28734 • tektone@tektone.net
Phone: (828) 524-9967 • Fax: (828) 524-9968 • Tech Support: Choose option 2 • Sales: Choose option 3
TekTone®'s quality system is registered by UL® to the ISO 9001 standard. (Reference #10001510.)