

## Features

- Modular design
- Protected markings
- Multiple use
- Up to 4 digits per lamp
- Vertical or horizontal mounting

## Description

The CM800-series Annunciators are modular panels, permitting use in systems requiring from 16 to 344 annunciator lamps. The CM800 is suitable for use in emergency call, security alarm, services monitoring, and similar applications where visual and audible annunciation is required. (If audible indication is not needed, specify when ordering.) Identification markings are easily applied by dry transfer letter method or label maker.



**CM800/20 Annunciator  
 with AM800/36 Add-on Panel and OF202 Frame**

## Specifications

Power Required: 16 to 24 VAC or VDC  
 Connections: Screw terminals  
 Housings: Flush mounting, OH200  
 Lamps available only in multiples of four.

## Required Components

CM800-series Speaker Panel  
 AM800-series Add-On Panel  
 PK2019A Power & Control Unit  
 SS106 Transformer

## Housing and Frame Chart for CM800

Number of Lamps	Width		Frame	Width Overall
	Flush	Cut-Out		
4 - 20	OH201	4-1/2"	OF201	6-1/4"
24 - 56	OH202	8-1/2"	OF202	10-1/4"
60 - 92	OH203	12-1/2"	OF203	14-1/4"
96 - 128	OH204	16-1/2"	OF204	18-1/4"

OH200 Series wall cut-out ..... height: 16-1/4".....depth:3-7/8"

OF200 Series overall ..... height: 17-3/4".....depth:2-1/2"