

Features

- Automatic tone-off reset
- Reliable and rugged design

Description

The IR019B Remote Tone Speaker provides remote tone annunciation when connected directly to a PK2019A Power & Control Unit, and in parallel with a TekTone® CM800-series or DS100-series Annunciator Panel.

The tone speaker features a momentary contact tone-off button for tone silencing. Depressing the tone-off button silences the tone at all IR019B locations. The tone-off light remains illuminated while tone-silencing is enabled. When the emergency initiating device has been reset, the tone-off will automatically reset.

Specifications

Dimensions:	Height:	4.5" (115 mm)
	Width:	4.5" (115 mm)
Finish:	Satin brushed stainless steel	
Controls:	Individual replaceable push button with self-wiping contacts	
Indicators:	28 volt red light	
Speaker/Mic:	45-ohms, 2.5"	
Connections:	Pigtails	
Housing:	Standard 2-gang electrical box	

Required Components

CM800 Emergency Call System

–or–

DS100 Door Sentry & Emergency Alarm System

PK2019A Power & Control Unit

SS106 Transformer



IR019B Remote Tone Speaker