

## CM491-series & CM492-series Vandal Resistant Apartment Entry Panels IL500 Specification Sheet

Tek-ENTRY® Apartment Entry Systems • Rev. 11 - 11/2016

### Features

- Vandal resistant panel and push button actuators
- Weather resistant Mylar speaker
- Fully enclosed back box with knockouts
- Hands-free loudspeaker (or optional handset)
- Engraveable solid aluminum push button actuators
- Vandal resistant Lexan directories
- Slim-line surface mount frame option
- Tamper resistant mounting screws

### Description

The CM491-series vandal resistant apartment entry panel is available with 4, 8, 12, 16 or 20 buttons and includes an integral directory.

The CM492-series vandal resistant apartment entry panels are modular so that adding additional button panels (if required), directory panels, frame and housing will comprise a complete entrance panel.

Panels are equipped with a Mylar voice-frequency response speaker protected by a louvered grill and perforated aluminum material. The aluminum push button actuators may be engraved with up to four letter/digit combinations.

### Specifications

Dimensions:	Height: 16.5" (418 mm)
	Width: 4" (100 mm)
Speaker:	2.5" (63.5 mm) Mylar
Construction:	Modular extruded anodized aluminum
Flush Mount:	CM491: OF291 frame, OH191 housing
	CM492: OF190-series frame, OH190-series housing
Surface Mount:	CM491: OF291S frame
	CM492: OF190S-series frame
Plungers:	Engraved extruded aluminum
Push Button:	Individually replaceable with self-wiping contacts



CM491/016  
OF291 Frame



CM492/024  
OF192 Frame and  
AM190D Directory

### CM491-series & CM492-series Vandal Resistant Apartment Entry Panels

### Required Components

IR-series Speaker-type Remote Stations  
PK543A Apartment Intercom Amplifier  
RP055EN Apartment Number Button Engraving  
SS102A or SS106 Transformer

*For CM491-series, add:*  
OF291 Frame and OH191 Housing, or OF291S Frame

*For CM492-series, add:*  
AM190D Directory Panel  
OF190-series Frame and OH190-series Housing, or  
OF190S-series Frame