

LI381 Corridor Light & LI382 Corridor Zone Light IL518 Specification Sheet

Tek-CARE® Nurse Call & CM800 Emergency Call Systems • Rev. 21 - 01/2017

Features

- UL® 1069 Listed
- Snap-in lens
- Easy bulb replacement
- Attractive flame-retardant HIPS30 plastic panel
- Excellent visibility

Description

The LI381 Corridor Light and LI382 Corridor Zone Light provide visual indication of calls when used with a nurse call system, emergency call system, or similar application. Emergency calls are indicated by the rapid flashing of the LI381 Corridor Light associated with the calling station. Normal calls produce a steady illumination.

The LI382 Corridor Zone Light indicates an emergency call by the rapid flashing of the red-covered bulb associated with the zone or area from which an emergency call has been placed. Normal calls are indicated by a steady illumination of the white bulb. If an emergency and normal call are placed in the same zone at the same time, the red covered bulb connected to the emergency station will flash rapidly, while the white bulb associated with the normal call will maintain a steady illumination.

The standard mounting plate accommodates both models and features an easily removable white flame-retardant translucent polystyrene plastic lens for bulb replacement.

Listings



UL® 1069 listed; UL® File Number E71599.



LI381 Corridor Light & LI382 Corridor Zone Light

Specifications

Dimensions:	Height:	4.5625"	(115 mm)
	Width:	4.5625"	(115 mm)
	Depth:	3.3"	(84 mm)
Bulbs:	#1829 28V 70 mA		
Power:	LI381:	24 VDC or VAC, 51mA	
	LI382:	24 VDC or VAC, 102mA	
Finish:	White flame-retardant translucent polystyrene plastic lens mounted on a flame-retardant (UL® 94V-0) plastic panel.		
Housing:	Fits either standard dual gang box and ring or single gang box and ring.		

Applicable Systems

Tek-CARE® NC110, NC150, NC200 or NC300II Nurse Call System

Tek-CARE®500 Wireless Emergency Call System with NC50xES-series remote receiver
CM800 Emergency Call System

www.tektone.com

324 Industrial Park Road • Franklin, NC 28734 • tektone@tektone.net

Phone: 828.524.9967 • Fax: 828.524.9968 • Sales: Choose option 2 • Tech Support: Choose option 3
TekTone's quality system is registered by DQS to the ISO 9001 standard. (Reference #10001510.)