

Features

- Simple, reliable operation
- Call-placed indicator
- Buzzer for audible annunciation
- Mounted on flame retardant (UL® 94V-0) plastic faceplate

Description

The LI150B Duty Station provides an indication of incoming calls in work areas away from the nurse call master station.

Normal calls are indicated both visibly by steady illumination of the solid-state LED light, and audibly by a slow pulsating tone. Emergency calls take precedence and are indicated by flashing of the LED light and a rapid pulsating tone. A Tone Off switch permits silencing of the tone signal for routine level calls only.

Listings



UL® 1069 Listed; UL® File Number E71599.

Specifications

Dimensions:	4.5"H × 2.75"W × 1"D (114 mm × 70 mm × 25 mm)
Connections:	Screw terminals
Construction:	Reliable components mounted on a flame retardant (UL® 94V-0) plastic faceplate
Housing:	Single-gang ring, or single-gang ring with dual-gang box



LI150B Duty Station

Required Components

Tek-CARE® NC110, NC150 or NC200 Nurse Call System