

Features

- UL® 1069 Listed
- Simple, reliable operation
- Call-placed indicator
- Buzzer for audible annunciation
- Mounted on rugged, flame-retardant (UL® 94V-0) plastic panel

Description

The LI150B Duty Station provides an indication of incoming calls in work areas away from the nurse call master station.

Normal calls are indicated both visibly by steady illumination of the solid-state LED light, and audibly by a slow pulsating tone. Emergency calls take precedence and are indicated by flashing of the LED light and a rapid pulsating tone. A tone-off switch permits silencing of the tone signal for routine level calls only.

Listings



UL® 1069 listed; UL® File Number E71599.



LI150B Duty Station

Specifications

Dimensions:	Height:	4.5"	(114 mm)
	Width:	2.75"	(70 mm)
	Depth:	1"	(25 mm)
	Projects:	0.5"	(13 mm)
		from mounting surface	
Construction:	Reliable components mounted on a flame-retardant (UL® 94V-0) plastic faceplate		
Connections:	Screw terminals		
Housing:	Single gang ring, or single gang ring with double gang box.		

Required Components

Tek-CARE® NC110, NC150 or NC200 Nurse Call System
IR150-series or SF100-series Patient Stations