

Features

- UL® 1069 Listed
- Place calls using 6' washable TPU plastic pull cord
- Call-placed indicator
- In-use indicator when intercom audio path is active
- Reset button
- Sensitive speaker/microphone
- Attractive and durable flame-retardant (UL® 94V-0) plastic panel
- May be used as a retrofit for the IR155N station with IH106N backbox; requires two CL207 mounting adapters.

Description

The IR155B Patient Station provides for efficient use of the nursing staff by permitting fast and reliable communication between staff and patient.

Calling the nurse is accomplished by pulling the 6' call cord. Call-placed assurance and intercom operation are indicated by solid-state LEDs.

The speaker/microphone is sensitive enough to assure clear conversation, even with weak patients. A reset switch is provided on the durable, flame-retardant (UL® 94V-0) plastic panel.

Listings



UL® 1069 listed; UL® File Number E71599.



IR155B Single Patient Station

Specifications

Dimensions:	Height:	4.5"	(119 mm)
	Width:	6.375"	(162 mm)
	Depth:	1.875"	(48 mm)
	Projects:	0.5"	(12.7 mm)

above mounting surface

Speaker: 2.5" x 2.5"

Connections: Plug-in type

Housing: Steel City #H3BD with Steel City #3GC plaster ring, or TekTone #IH353 box with IH352 ring, or equal, or if a smaller box is needed, use ARC-CO #2GB with ARC-CO #3GC ring. Horizontal mount.

Required Components

Tek-CARE® NC200 or NC150 Nurse Call System