

Features

- Place calls using 6' washable TPU plastic pull cord
- Call-placed indicator
- In-use indicator when intercom audio path is active
- Reset button
- Sensitive speaker/microphone
- Durable flame retardant (UL® 94V-0) plastic panel
- May be used as a retrofit for the IR155N station with IH106N back box; requires two CL207 mounting adapters

Description

The IR155B Single Patient Station provides for efficient use of the nursing staff by permitting fast and reliable communication between staff and patient.

Calling the nurse is accomplished by pulling the 6' call cord. Call-placed assurance and intercom operation are indicated by solid-state LEDs.

The speaker/microphone is sensitive enough to assure clear conversation, even with weak patients. A reset switch is provided on the durable, flame-retardant (UL® 94V-0) plastic panel.

Listings



UL 1069 Listed; UL® File Number E71599.

Specifications

Dimensions:	4.5"H × 6.375"W × 2.375 "D (114 mm × 162 mm × 60 mm)
Construction:	Flame retardant (UL® 94V-0) plastic
Speaker:	2.5" × 2.5"
Connections:	Plug-in type
Housing:	Steel City #H3BD with Steel City #3GC plaster ring, or TekTone #IH353 box with IH352 ring, or equal, or if a smaller box is needed, use ARC-CO #2GB with ARC-CO #3GC ring. Horizontal mount



IR155B Single Patient Station

Required Components

Tek-CARE NC150 or NC200 Nurse Call System