

# IR150SS, IR150SS/S, IR150SSF, IR150SS/SF Remote Call Stations

**IL765 Specification Sheet** 

Tek-SAFE® Area of Rescue Assistance System • Rev. 8 - 11/2016

#### **Features**

- Push button calling via large red mushroom-style or low-profile button
- Call-placed indicator
- Audio-on indicator
- Cancel button
- Sensitive speaker/microphone
- Attractive and durable stainless steel panel
- Weather resistant when properly installed

# **Description**

Used with TekTone's Tek-SAFE® NC150R Area of Rescue Assistance System, IR150SS-series Remote Call Stations provide efficient communication between areas of rescue assistance (in protected stairwells) and the building lobby.

IR150SS-series Remote Call Stations are located in areas of rescue assistance to provide two-way hands-free communication to a central location from which help may be summoned. Calls are placed by pressing a large, red momentary push button. Solid state indicators on the panel indicate when a call has been placed and when the intercom is in use.

- IR150SS is a flush mount station with a large mushroomstyle push button.
- IR150SS/S is a surface mount station with a large mushroom-style push button.
- IR150SSF is a flush mount station with a large lowprofile push button.
- IR150SS/SF is a surface mount station with a large low-profile push button.





IR150SS (top) & IR150SSF Remote Call Stations

## **Specifications**

Dimensions: Height: 5" (127 mm)

Width: 11.1" (282 mm)
Depth: 1.75" (45 mm)

Projects: 1.5" (38 mm) above mounting

surface (IR150SS)

Projects: 3.5" (89 mm) above mounting

surface (IR150SS/S)

Construction: Durable stainless steel panel

Finish: Brushed stainless Speaker: 3.5" Mylar®

Connections: 6-screw terminal block

Housing: TekTone® OH600 or equal for IR150SS and

IR150SSF; none required for IR150SS/S

and IR150SS/SF.

## **Required Components**

Tek-SAFE® Area of Rescue Assistance System