

### Features

- UL® 1069 Listed
- Routine audible-visual signaling
- Emergency audible-visual signaling
- Voice communication and monitoring
- Push button operation
- Nurse-follow capability
- Modular design
- Integrated circuit technology

### Description

The basic Tek-CARE® NC150 series Audio/Visual Nurse Call System consists of patient calling stations; emergency call stations; a master intercom/annunciator station including amplifier, dome lights, zone lights; and reliable, solid-state control and power supply equipment. The flexible, modular design permits simple, customized installation.

Emergency signals are distinctively identified by a rapid pulsating of all visual and audible signals associated with the calling station. If routine and emergency calls are present simultaneously, emergency signaling is given precedence. Emergency audible signals can only be canceled at the point of origin.

Sensitive two-way voice communication, Nurse Follow, Tone-Off, Tone Call functions are push button selected.

Optional equipment is available to provide for staff stations, duty stations, remote visual annunciator, master handset, and a third priority level annunciation.

### Listings



UL® 1069 listed; UL® File Number E71599.



NC150/12 with OF202 Frame and TA150N Handset

### Required Components

NC150-series Master Station Panel  
AM150-series Add-on Panel with station selector/light buttons and test button  
OF200-series Frame  
OH200-series Housing  
IH151NK Power and Control Kit

### Optional Components

TA150N Handset Panel  
IH300-series Desk Cabinet  
OH300-series Surface Housing  
PK124K Battery Backup Kit  
PK153 Third Priority Control Unit