

Features

- Routine audible-visual signaling
- Emergency audible-visual signaling
- Voice communication and monitoring
- Push-button operation
- Nurse-follow capability
- Modular design
- Integrated circuit technology

Description

The basic Tek-CARE®NC150 Audio/Visual Nurse Call System consists of patient calling stations; emergency call stations; a master intercom/annunciator station including amplifier, dome lights, zone lights; and reliable, solid-state control and power supply equipment. The flexible, modular design permits simple, customized installation.

Emergency signals are distinctively identified by a rapid pulsating of all visual and audible signals associated with the calling station. If routine and emergency calls are present simultaneously, emergency signaling is given precedence. Emergency audible signals can only be canceled at the point of origin.

Sensitive two-way voice communication, Nurse Follow, Tone Off, and Tone Call functions are push-button selected.

Optional equipment is available to provide for staff stations, duty stations, remote visual annunciator, master handset, and a third priority level annunciation.

Listings



UL® 1069 Listed; UL® File Number E71599.



NC150/12 with OF202 Frame and TA150N Handset

Required Components

NC150-series Master Station Panel
AM150-series Add-on Panel with station selector/light buttons and test button
OF200-series Frame
OH200-series Housing
IH151NK Power & Control Kit

Optional Components

TA150N Handset Panel
PK124K Battery Backup Kit
PK153 Third Priority Control Unit