

Features

- Vandal resistant panel and push-button actuators
- Weather-resistant Mylar speaker
- Fully-enclosed back box with knockouts
- Modular design
- Hands-free loudspeaking
- Individually replaceable name holders (black flame retardant polycarbonate plastic)
- Self-wiping push-button switches
- Slim-line surface mount option

Description

The AM492-series Vandal Resistant Apartment Entrance Panel is a modular series for use with TekTone® apartment intercom stations. Panels are equipped with a Mylar, voice-frequency response speaker protected by a louvered panel and perforated aluminum material. The speaker panel can accommodate up to 18 push buttons. For more than 18 apartments, the AM492 is used with the AM490/12 or AM490/22 push-button add-on panel.

Pressing the button corresponding to the desired name and apartment number causes a buzzing at the apartment station. The resident may then converse with the caller. Controlled entry is permitted by push-button operation of the electric door release. AM492 panels with 0–10 buttons are available with postal option.

Specifications

Dimensions:	16.5"H × 4"W (419 mm × 102 mm)
Speaker:	2.5" (64 mm) Mylar
Push Button:	Individually replaceable with self-wiping contacts
Construction:	Modular extruded, anodized aluminum panel and push-button actuators
Housings:	OH190-series for flush mounting OF190S-series frame for surface mounting



AM492-series Entrance Panel with OF191 Frame

Required Components

IR-series Apartment Intercom Stations
OF190-series Frames
OH190-series Housings
PK543A Apartment Intercom Amplifier
SS102A or SS106 Transformer