

Description

The PO101S Postal Door Release provides for postal lock installation and microswitch control of door release devices. It is constructed of a rugged aluminum panel with durable, flame retardant ABS plastic endcaps. The extrusion design provides sufficient depth to make the panel surface mountable with no additional housing required. A gasket is also attached to the rear surface to increase the station's resistance to weather exposure.

Specifications

Dimensions:	Height:	7.25"	(184 mm)
	Width:	4.9"	(125 mm)
	Depth:	1.5"	(38 mm)
Construction:	Rugged extruded aluminum panel with durable, flame retardant ABS plastic endcaps		
Finish:	Brushed aluminum		

Required Components

Tek-ENTRY® Apartment Entry System
-or- Tek-ENTRY® Vandal-Resistant Entry System



PO101S Postal Door Release